

Drive On with First-Class Service.



Ford Protect PremiumCARE coverage is 100% Backed by Ford Motor Company.

- Service provided at Ford and Lincoln dealerships in the U.S., Canada and Mexico
- Ford-authorized parts used for covered repairs
- Factory-trained and certified technicians

Drive On with Valuable Benefits.



Ford Protect PremiumCARE coverage is there when you need it with 24-hour Roadside Assistance.

- Includes tire change, lockout, out-of-fuel and battery jump-start assistance
- Towing Assistance (up to \$100 per occurrence)
- Emergency Travel Expense (up to \$500 within the first 3 days per occurrence)
- Destination Assistance (up to \$75)

Call 1-800-241-3673

Plus, Rental Vehicle Benefits.

- Coverage of \$30 a day for up to 10 days for covered repairs

Drive On with Savings.



Ford Protect PremiumCARE coverage is an affordable way to limit your out-of-pocket expenses.

- Protects you from the rising cost of future repair bills
- Pay only your deductible, if any, per covered repair visit
- 100% transferable, which may increase your vehicle's resale value (transfer fee applies)

Drive On with Key Services Option.



Ford Protect Key Services Option has you covered against lost, stolen or damaged keys and key fobs.

- If your key and/or fob are ...
 - Misplaced
 - Damaged and will not work
 - Locked in your vehicle
- Your plan will ...
 - Replace or reprogram your key(s) and/or fob(s)

Not available in all states.

For New Ford Protect Plans:

- Coverage begins with the original in-service date (New Vehicle Limited Warranty start date) and zero miles or hours. Your selected coverage expires upon reaching the earliest of time, mileage or hours.

For Used Ford Protect Plans:

Vehicles within the New Vehicle Limited Warranty

- Eligible Ford, Lincoln and Mercury vehicles that have New Vehicle Limited Warranty remaining at the time of purchase – coverage begins at the signature date and current mileage. Coverage ends at the earlier of the number of months purchased or the number of miles purchased from the expiration of the New Vehicle Limited Warranty.

Vehicles outside the New Vehicle Limited Warranty

- Coverage for Ford, Lincoln and Mercury vehicles beyond the New Vehicle Limited Warranty and all competitive-make vehicles begins at the signature date and current mileage. Your selected coverage expires upon reaching the earliest of time, mileage or hours.

For Cab and Chassis/Incomplete Vehicles:

- A variety of unique time/mileage/hour options and deductibles are available within 5 years or 100,000 miles or 4,000 hours of the original in-service date.
- Coverage begins with the original in-service date (New Vehicle Limited Warranty start date) and zero miles or hours. Your selected coverage expires upon reaching the earliest of time, mileage or hours.

0% APR interest-free Installment Payment Plan

with flexible payment options is available when the extended service plan is not included in the vehicle financing; everyone qualifies, making it the smart choice.



FORD PROTECT®

This brochure is intended to provide general information about a PremiumCARE Extended Service Plan offered by Ford Protect. It was printed for the October 2017 plan year. Prices and plan details may have changed after the brochure was printed. Plan availability, benefits, coverage and provider may vary by state. Please refer to your plan's service contract for the actual terms and conditions.

In Florida, Ford Protect on Ford vehicles is a Service Contract from Ford Motor Company (License #12118). Ford Protect on competitive-make vehicles is a Service Contract from The American Road Insurance Company, Dearborn, MI 48126 (Certificate of Authority #09079).

In Texas, Ford Protect is a Service Contract from Ford Motor Service Company (License #SCP-165).

FORD PROTECT®

PremiumCARE

Extended Service Plan



Go Further

Drive On with Confidence.

With a Ford Protect PremiumCARE Extended Service Plan, you are protected from unforeseen covered repairs on your vehicle for up to the earlier of 8 years or 150,000 miles.



That's well beyond the New Vehicle Limited Warranty that comes with your vehicle. Now is the time to protect your investment with a Ford Protect PremiumCARE Extended Service Plan.

Why Ford Protect PremiumCARE is such a great value.

The price for parts and labor to repair many major components can be significant. One repair bill can easily exceed the price of your Ford Protect PremiumCARE coverage. It's clear that this coverage can quickly pay for itself!

Engine*
~~\$5,863~~

Steering Gear*
~~\$1,708~~

Transmission*
~~\$5,782~~



Airbag*
~~\$1,048~~

Headlamp/Tail Lamp Assembly*
~~\$1,954~~

A/C Evaporator Core*
~~\$1,994~~

	DEDUCTIBLE OPTIONS	
	STANDARD	OPTIONAL
New Ford and Competitive-make Vehicle Plans	\$100	\$0, \$50, \$200, Disappearing
Used Ford and Competitive-make Vehicle Plans	\$100	\$50, \$200, Disappearing

*These examples are based on an average estimated U.S. retail repair cost for 2013-2016 Escape. Actual repair costs will vary by vehicle and dealer location.

Drive On with Peace of Mind.

Based on your driving needs, you can customize a Ford Protect PremiumCARE Extended Service Plan that's right for you.

TIME AND MILEAGE OPTIONS (Hours Not Shown) Available within New Vehicle Limited Warranty

Plan Length or Miles Covered (Coverage ends at the earlier of years or mileage)	3 Years	4 Years	5 Years	6 Years	7 Years	8 Years
36,000 Miles	■	■	✓	✓	✓	✓
48,000 Miles	✓	✓	✓	✓	✓	✓
60,000 Miles	✓	✓	✓	✓	✓	✓
75,000 Miles	✓	✓	✓	✓	✓	✓
100,000 Miles	✓	✓	✓	✓	✓	✓
125,000 Miles	✓	✓	✓	✓	✓	✓
150,000 Miles	✓	✓	✓	✓	✓	✓

USED PLAN TIME AND MILEAGE OPTIONS Available Beyond the New Vehicle Limited Warranty

Coverage lengths range from 1 year/12,000 miles to 5 years/75,000 miles for 2006 and newer vehicles.

ENGINE

- All Internally Lubricated Parts
- Cylinder Block
- Cylinder Heads
- Diesel Fuel Injectors
- Diesel Injector Lines
- Diesel Injector Pump
- Diesel Lift Pump
- Engine Mounts
- Flywheel
- Flywheel Ring Gear
- Fuel Tank and Metal Lines
- Gas Fuel Injectors
- Gas Injector Lines
- Harmonic Balancer and Bolt
- Manifold (Exhaust and Bolts)
- Manifold (Intake and Bolts)
- Oil Pan
- Oil Pump
- PCM Module
- Radiator
- Radiator Fan (Clutch or Motor)
- Seals and Gaskets
- Thermostat
- Thermostat Housing
- Timing Chain Cover
- Timing Chain (Gears or Belt)
- Turbocharger/Supercharger Unit (Factory-Installed)
- Valve Covers
- Water Pump

TRANSMISSION

- All Internally Lubricated Parts
- Release Hubs and Bearings
- Seals and Gaskets
- Torque Converter
- Transfer Case (Including All Internal Parts)
- Transmission Case
- Transmission Linkage
- Transmission Module (External)
- Transmission Mounts

ELECTRICAL

- LED Lighting or Lamp Assemblies – Interior and Exterior (Factory-Installed)*
- Alternator
- Audiophile Sound System
- Charge and Volt Gauges
- Clock (Electric)
- Control Trac® 4WD System
- Driver's Seat Position Sensor
- Dual-Zone Electronic Auto Temp Control
- Electronic Ignition Module
- Fuel Pump
- Heated Backglass (Electrical Only – Not Glass Damage or Breakage)
- High-Intensity Discharge (HID) Headlamps*, Igniter, Ballast
- Ignition Coil and Lock
- Ignition Module (Electric)
- Ignition Switch
- Incandescent/Halogen Bulbs – Interior and Exterior*
- Intelligent 4WD Systems
- Power Mirrors (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Power Running Boards
- Radiator Fan Relay
- Rear Window Power Sunshade
- Speedometer/Odometer (Electrical and Mechanical)
- Starter Motor
- Starter Motor Solenoid
- Switches (Manually Operated Electrical)
- Temperature Gauge or Breakage
- Voltage Regulator
- Wiper-Activated Headlamps
- Wiper Motors
- Wiring Harnesses (Excluding Spark Plug Wires)

BRAKES

- Anti-Lock Brake Module and Sensor
- Backing Plates
- Brake Booster (Power)
- Calipers
- Combination Valve
- ETA Pump Hose Assembly
- Metal Lines and Fittings
- Master Cylinder
- Parking Brake Linkage and Cables
- Retainers and Clips
- Self-Adjusters
- Shaft (Brake Pedal)
- Springs
- Wheel Cylinders

FRONT AND REAR SUSPENSION

- Ball Joints (Upper and Lower)
- Control Arms (Upper and Lower)
- Control Arm Shafts and Bushings
- Kingpins and Bushings
- Linkage and Bushings
- Load Leveler Suspension System
- MacPherson Struts
- Roll Stability Control
- Spindle and Spindle Support Springs
- Stabilizer Bar
- Tie Rods

REAR/FRONT-WHEEL-DRIVE AXLE

- Axle Shafts
- Bearings (Front and Rear)
- Rear: Drive Axle Housing and Front Axle Housing for 4x4 (Including All Internal Parts)
- Front: Final Drive Housing and Rear Axle Housing for AWD (Including All Internal Parts)
- Driveshaft
- Hubs, Automatic Front Locking (Four-Wheel Drive)
- Locking Rings (Four-Wheel Drive)
- Seals and Gaskets
- Universal and Constant Velocity Joints

EMISSIONS

- Air Check Valve Assembly
- Air Control Valve
- Air Idle Vacuum Valve
- Air Supply Valve (Hose and Tube)
- Barometric Pressure Sensor
- DEF System (Excludes Catalyst)
- ECC Relay Assembly
- EGR Control Valve
- EGR Pressure Sensor
- EGR Regulator Assy
- EGR Valve Adapter
- Electronic Throttle Control
- EVAP Vapor Storage Canister
- Idle Air Control Valve
- Knock Sensor
- Mass Air Flow/Intake Air Temp Sensor
- Oxygen Sensor
- PCV Hose Assembly
- PCV Valve
- PCV Vapor Filter
- Reductant Urea System
- Temperature Sensor (Engine Coolant)
- Vacuum Restrictor
- VAF Sensor
- Variable Camshaft Timing (VCT) Phasers

AIR CONDITIONING & HEATING

- A/C Accumulator
- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Condenser
- Auto Temp Control
- Evaporator
- Field Coil
- Heater Blower Motor
- Heater Control Assembly
- Heater Core Assembly
- Instrument Panel Registers and Air Ducts
- Pulley

HIGH-TECH

- Adaptive Cruise Control
- Adaptive Headlamp System (Excluding Lamp Housing, Bulbs)
- Air Suspension (Selected Electronic Components)
- Anti-Theft Alarm (Factory-Installed)
- Auto Lock and Auto Unlock System
- Automatic Park Assistant
- FordLink™ System
- Ford Work Solutions Asset Security (if equipped)
- Forward Sensing Sys
- Fuel Mixer (Alternative)
- In-Dash Garmin® Voice-Activated Navigation System (Factory-Installed and Dealer)
- Instrument Cluster (Excluding Dash Pad)
- Intelligent Oil Life Monitor® System
- Keyless Entry System (Excluding Door Handles)
- Message Center
- Parallel Park Assist Sys
- Power Antenna
- Power Door Locks and Retainer Clips (Excludes Door Handles)
- Power Seat Motors
- Power Window Motors/Regulators
- Rain-Sensing Wipers
- Rear Console Refrigeration
- Reverse Camera Sys
- Reverse Sensing Sys
- SecuriCode™ Keyless Entry
- SecuriLock® Passive Anti-Theft Ignition System
- Sensor (Alcohol)
- SOS Post-Crash Alert System
- Speed Control
- Stationary Elevated Ride Control
- SYNC® MyFord Touch® (Excludes Software Upgrades)
- Trailer Brake Module
- Unique Hybrid/Electric Vehicle Components (Excluding High-Voltage Battery and Cables)

AUDIO

- Antenna, Radio (Base Assembly)
- Brackets
- Cables and Wiring
- Cellular Phone, Receiver, Handset, Speaker Assembly and Antenna (Factory-Installed)
- Compass and Therm Readout Displays
- Controls (Rear Seat)
- Radio (AM, AM/FM), Speakers, Cassette Player, Digital CD Player, Graphic Equalizer, Premium Sound Amplifier (Factory-Installed)
- Rear Entertainment System (Factory-Installed)

SAFETY

- Airbag Module Assembly
- Blind Spot Info Sys (Electrical Only – Not Mirror or Glass Damage or Bulbs)
- Collision Avoidance Sys
- Cross-Traffic System
- Diagnostic Module Assembly (Airbag)
- Door Ajar Warning Switch Assembly
- Guides, Bezels, Brackets and Supports (Safety Belts/Shoulder Straps)
- Head Restraint Retainers and Sleeves (Safety Belt)
- Key, SecuriLock® (Microchip-Encoded Key)
- Lane Depart Warning
- Lock Cylinder (Door)
- Lock Lever Assy (Door)
- Lock Lever Retainers, Clips and Brackets
- Module (Passive Restraint)
- Safety Belt Buckle (Front and Rear)
- Safety Belt Motor Drive Assembly
- Safety Belt Restraint Carrier
- Safety Belt Retractors
- Safety Belt Track Assy
- Safety Belt Warning Chime Assembly
- Safety Canopy
- Sensors (Airbag)
- Shoulder Strap Track Assembly
- Wiring Assy (Airbag)

STEERING

- Column Lock (Tilt Wheel)
- Control Valve
- Cooler and Metal Lines
- Electronic Power-Assisted Steering
- Idler Arm
- Power Steering Pump/Electric Power Steering Actuator
- Pulley Assembly
- Seals and Gaskets
- Steering Column
- Steering Gear Housing, Manual and Power (Including All Internal Parts)
- Steering Shaft
- Underbody Linkages and Couplings

100% Backed by Ford

24-hour Roadside Assistance
1-800-241-3673

1,000+ Covered Components

Rental Benefits

Ford-authorized Parts

Transferable

Service in the U.S., Canada and Mexico

Ford Certified Technicians

Key Services Option



The Ford Protect PremiumCARE Extended Service Plan is so comprehensive, it's easier to refer you to what isn't covered – here are the highlights:

Generally Covered by Your Auto Insurance – Examples include: fixed (non-moving) body parts, bumpers, glass, moldings, ornamentation, paint, rust, sheet metal, structural underbody framework, side and rearview mirrors (glass and housing), water leaks, wind noise, weather strips, wheels, wheel studs, wheel covers, convertible top and bow.

Repairs Related to Your Maintenance Requirements – Items listed in your vehicle's owner guide. Examples include: batteries of all types and cables, belts, hoses, hose clamps, brakes (front hub, drums, shoes, linings, disc rotors, pads), manual transmission clutch disc, exhaust system (includes catalytic converter), spark plugs, squeaks, rattles, tires, wheel balancing, wheel alignment, all lamps and lights (LED and HID lights, bulbs, sealed beam and lenses) except when purchased with New or Incomplete PremiumCARE Interior/Exterior Lighting Option, fogging of lamp assemblies, shock absorbers, service adjustments and cleaning, and scheduled maintenance services.

Other Components and Repairs – Fabric, liners, fasteners, carpets, dash pad, wiper blades, knobs, trim, upholstery, physical damage or cosmetic issues, repairs covered by manufacturer recalls, any insurance or if the vehicle is within the time and mileage limits of any warranty, repairs caused by improper unreasonable use, unauthorized alterations or modifications of the vehicle, and repairs caused by lack of required or recommended maintenance. Costs or expenses for the teardown, rental expense, inspection or diagnosis of failures not covered by this Agreement. Refer to contract for details.

*Interior/Exterior Lighting – coverage included only if Lighting Option is purchased.